

# Z1

## User Guide



Rel: 2.01

<b>Release</b>	<b>Date</b>	<b>Changes</b>
1.00	23/02/2016	First release
2.00	23/09/2016	Updated for 24V system
2.01	12/01/2017	Accessories updated

---

## Index

GENERAL INFORMATION.....	4
SAFETY REGULATIONS .....	11
TECHNICAL SPECIFICATIONS .....	20
TRANSPORT, PACKAGING AND STORAGE .....	24
CONSTRUCTION AND FUNCTION .....	30
INSTALLATION AND INITIAL OPERATION .....	41
OPERATION .....	58
Z1 REMOTE MANAGER .....	80
FAULTS.....	82
DISASSEMBLY.....	88
LIST OF ACCESSORIES AND SPARE PARTS.....	91
APPENDIX .....	96

---

# 1. General Information

## General Survey

---

Congratulations! You have purchased a high-quality print system. Our concern is to make sure that you profit from this system to your entire satisfaction over many years. In order to ensure this, we strongly recommend you to let our experienced specialists perform the installation.

## Limitation of Liability

---

All pieces of information and notes of this manual have been arranged in consideration of applicable standards and regulations, state-of-the-art technology as well as our cognition and experiences over many years.

The manufacturer assumes no liability for damages caused by:

- Non-observance of this manual
- Non-observance of the intended use
- Use of unqualified personnel
- Manipulations at the system
- Technical changes
- Use of spare parts that are not approved by the manufacturer

The actual scope of delivery may differ from the explanations and illustrations provided herein in the case of special designs, additional order options or after recent technical changes.

The obligations of the supply contract the General Trading Conditions as well as the Terms of Delivery of the manufacturer and the valid legal regulations at the moment of conclusion of a contract generally apply.

Technical changes within the scope of improvement and development are subject to change without notice.

## Warranty Clause

---

The warranty conditions are conform to the valid General Trading Conditions of the manufacturer at the moment of purchase.

**Copyright Protection**

---

This documentation or parts of this documentation may only be copied, photocopied, reproduced or translated into other languages for personal use. Without previous expressed written permission of **Zanasi s.r.l.** a reproduction for circulation to a third party is not permitted.

---

## Purpose and Scope of this service manual

---

This manual enables safe and effective use of the Zanasi Z1.

The Operating manual is a component of the device and must be stored close to the device to be accessible to the staff at all times. The staff must have read this manual thoroughly and understand the content before starting any work. Compliance with all safety notes and instructions given in this manual is a basic prerequisite to safe operation.

Furthermore, the local accident prevention regulations and general safety provisions for the area of application of the device are applicable.

Images in this manual serve to provide a basic understanding and may differ from the actual device version.

---

## Hints for Use of this Manual

---

Please find in the following a detailed explanation of the notations and representations used in this manual.

Keys and buttons which you must push appear in squared brackets.

Example: Push [Enter] - button to save changes...

Procedures which should be followed in a specific order are listed in numbered paragraphs.

Step	Procedure
1	Disconnect power plug

---

Important messages are written in bold text and/or highlighted in grey.

**This is an example for an important message!**

Special notes:

---

⇒ ... refers to a result, following an action by the operator.

---

→ ... refers to a chapter or document.

---

Figures and drawings are numbered serially in the particular chapter. For example „**Fig. 2-1**“ is the first figure in chapter 2.

---

**Explanation of Technical Terms**


---

Technical Term	Explanation
<b>CartClip</b>	Cartridge holder for storage of already opened cartridges to protect them against leaking or drying out of nozzle plate
<b>Conveyor</b>	The conveyor transports the products, which should be printed and pass them by the print head
<b>DPI</b>	<b>Dots Per Inch</b>  1 Inch = 25,4mm
<b>Encoder</b>	A shaft encoder is used for the automatic detection of the conveyor speed and defines the print speed
<b>Flexbracket</b>	Flexible mounting bracket of the control system.
<b>Funai-Lexmark</b>	Manufacturer of the ink cartridges
<b>Ink cartridge</b>	Original Funai-Lexmark cartridge
<b>LED</b>	Light emitting diode
<b>Left-hand</b>	Installation of the system with cartridge holder on the left side
<b>Nozzle plate</b>	On the nozzle plate is the two-rowed arrangement of per 300 nozzles, which ejected the ink.
<b>Print direction</b>	Direction of movement of the product on the conveyor belt viewed from the control system in the print direction
<b>Print intensity</b>	Contrast of the print image. If necessary this parameter must be changed to optimize the print image. A higher intensity gives greater blackening and longer ink drying time
<b>Print speed</b>	Print speed = Speed of the conveyor. The speed of the conveyor must be keep constant
<b>Print start delay</b>	Offset print, i.e. by how much is printing delayed in millimeters after the product is detected by the product sensor.



---

<b>Print width</b>	The number of pixel can be increased or decreased using this parameter. The print image becomes narrower or wider.
--------------------	--

---

<b>Product sensor</b>	A sensor for the detection of the product. Mostly used are optical sensors (photo sensor, reflex sensor)
-----------------------	--

---

<b>Right-hand</b>	Installation of the system with cartridge holder on the right side (standard configuration)
-------------------	---

---

<b>TIJ</b>	Thermal Ink Jet
------------	-----------------

---

<b>CartClip</b>	Cartridge holder for storage of already opened cartridges to protect them against leaking or drying out of nozzle plate
-----------------	---

---

---

---

## Customer Service

---

Please contact your local distributor for technical information.

If failures at the print system occur, you should be prepared with the following information:

- Detailed error description.
- All information on the name plate of the print system
- Version number of the system software and of the Z1 Remote Manager software
- Configuration (Advanced, Pro)
- Special functions of the software or hardware
- When did the error occur for the first time?

Prior to call our hotline service, please have a look at the manual for potential references to eliminate the error.

Furthermore, our staffs are always interested in new information and experiences with the use of the product and which may be valuable for improvements to our products.

---

## 2. Safety Regulations

### Behavior in Case of an Emergency

---

The operating personnel have to be familiar with the operation and the location of safety, accident notification-, first aid- and rescue devices.

### What to do in Case of an Emergency?

---

- Initiate immediately all required emergency measures for injured persons. Observe valid safety regulations in any case in order to avoid further damages to persons.
- Call medical attendance for injured persons.
- Eliminate all accident causes.

### General Safety Regulations

---

Safety regulations provide information in written and symbol form in order to warn you against dangers and to instruct you to avoid any damage to persons or to properties.

Safety regulations are started by signal words indicating the level of danger.

Safety regulations may be placed directly at the print system or in documents about this print system.

### Explanation of Danger Degrees

---



This symbol indicates a hazardous situation which, if not avoided, will result in death or serious injury. All safety regulations have to be observed to avoid any damage to persons.

---



This symbol indicates a hazardous situation which, if not avoided, could result in death or serious injury. All safety regulations have to be observed to avoid any damage to persons.

---



This symbol indicates a hazardous situation which, if not avoided, may result in minor or moderate injury. All safety

---

regulations have to be observed to avoid any damage to persons.

---

**NOTICE**

This symbol indicates a hazardous situation which, if not avoided, may result in damage to properties. All safety regulations have to be observed to avoid any damage to properties.

---

## Intended Use

---

The working reliability of the print system is ensured only with intended use.

The Z1 has been designed, built and must be used exclusively for the intended purpose described.

The Z1 serves to create print images and to print these from the top or side onto smooth and absorbent product surfaces. The product must pass the Z1, i.e. positioned on a conveyor belt

All working conditions and instructions, prescribed in this manual, will be observed.

Any use beyond the intended use or any alternative use of the equipment is regarded as misuse and may lead to hazardous situations.

**Misuse of the device may lead to hazardous situations. Refrain, in particular, from subjecting the apparatus to the following:**

Any claims arising from damages due to undesignated use are rejected.

---

## Reasonably Foreseeable Misuse

---

Another use as fixed in the „Intended Use“ or even more applies as not intended!

For damages caused by not intended use

- the operator bears the complete responsibility,
- the manufacturer assumes no liability.

If you do not use the system according to the regulations, risks may occur!

### Not intended uses are e.g.:

- operation in explosive atmosphere
- the print system comes in contact with food

---

## Retrofitting and Changes at the Print System

---

Unauthorized retrofitting and changes at the system lead to an immediate expiration of liability and warranty covered so far by the manufacturer! This is also valid for interventions and program changes at programmable control systems as well as program changes at control units as far as they are not described in this Manual.

The electromagnetic performance of the system can be affected by amendments or changes of any kind.

Do not arrange any changes or amendments at the systems without consultation and written approval of the manufacturer.

---

## Warning Notices at Print System

---

Particular sources of danger at the print system are marked by yellow labels. The used pictograms point out to following dangers:



Danger to Life

---

## Special hazards

---

The following section identifies the remaining risks, determined following a risk analysis.

**Observe the safety notes listed here and the warnings in other chapters of the manual to minimize health hazards and avert hazardous situations.**

–



**Risk of injury through incorrect handling of batteries!**



**RISK OF INJURY!**

Rechargeable and primary batteries contain toxic heavy metals. They must be treated as special refuse and deposited at municipal collection points or be disposed of by a specialized company. Batteries must be handled with particular care.

Therefore:

- Never throw batteries into a fire or subject batteries to high temperatures. Explosion hazard.
- Do not charge batteries. Explosion hazard.
- Fluid escaping through incorrect use may cause skin irritations. Avoid contact with the fluid. In case of contact with the fluid, rinse with ample water. If the fluid comes into contact with the eyes, rinse immediately with water for 10 minutes and consult a doctor without delay.

**⚠ CAUTION****Edges and corners pose risk of injury!****RISK OF INJURY!**

Sharp edges and pointed corners may cause abrasions and cuts to the skin.

Therefore:

- Be cautious when working near sharp edges and pointed corners.
  - If in doubt, wear protective gloves.
- 

**⚠ CAUTION****Risk of stumbling posed by dirt, objects lying about and connecting lines!****RISK OF INJURY!**

Dirt, objects lying about and connecting lines for power, data- and signal lines may cause slipping and stumbling resulting in severe injuries.

Therefore:

- Always keep working area clean.
  - Remove objects no longer required.
  - Mark stumbling areas with yellow-black marking tape.
  - Non tension connecting lines to system and pass it that no places of danger do arise
-



## Remaining Risks

---

The print system is constructed for a safe operation. Hazards that are not preventable due to construction purposes are limited as far as possible by protection devices. A certain amount of risk is always existent! The knowledge about the remaining risks assists you to arrange your work safer and to avoid incidents. In order to avoid the dangers, please observe additionally the particular security advice in the single chapters.

## Disposal

---

This print system complies with the RoHS 2 EU-Regulation 2011/55/CE with observance of the fixed using prohibitions and avoiding pollutants.

## Unauthorized persons

---

Work at the print system should only be performed by reliable personnel.

Only trained personnel are allowed to operate the print system. Trainees, apprentices etc. must be supervised by an experienced person while working at the print system.

Prior to start running the labeler the operator has to ensure that the manual of the labeler is available to all users of the machine and that the users have read and understood the manual. Only then the system may be put in operation.

The responsibility for the different tasks at the print system must be clearly specified and kept. There must be no ambiguous authorities for this may put the safety of the users at risk. Arrange a detailed work schedule if several persons work on the machine.

All work on the electrical equipment must be carried out by skilled electricians only.

Failures may be eliminated by authorized personnel only.

All work associated with the assembly, adjustment and maintenance at the machine may be carried out only by trained or instructed personnel.

---

## Personal Protective Equipment

---

Wear following protective equipment when performing work at the system:



### SAFETY SHOES

Wear for protection against falling off parts and slipping.

---



### PROTECTIVE CLOTHING

Are tight-fitting clothes with low tensile strength, with tight sleeve and without distant parts

Wear a hairnet if applicable

Do not wear jewelry or wrist watches

---



### PROTECTIVE GOGGLES

For protection against splashes of detergents and flying parts





---



### SAFETY GLOVES

For protection against sharp-edged items

---

Personal Protective Equipment for the following tasks	Protective Clothing	Safety Shoes	Safety Gloves	Protective Goggles
				
Transport	x	x	x	
Setting up and connecting of the system	x	x	x	x
Maintenance Work	x		x	x
	The documentation of the manufacturer of the single system components has to be observed!			

### Working Places Operator Personnel

The print system is an automatic working system and does not require any operation for the printing procedure.

### 3. Technical Specifications

#### General

<b>Dimensions</b> (H x W x D)	97 x 82 x 122 mm (3.82 x 3.23 x 4.8 inch) excluded bracket, ink cartridge and connections
<b>Weight</b>	570 g
<b>Environmental Temperature:</b>	5 - 40 ° C
<b>Environmental Conditions:</b>	10-90 % relative humidity (non-condensing)
<b>Protection Rating</b>	IP 40
<b>Maximum operating time</b>	The system is designed for continuous operating

#### Electrical

<b>Voltage Power Supply:</b>	100 - 240 VAC / 50-60Hz (1~)
<b>Voltage System:</b>	max. 1,25 A @ 12V, 0,625 @ 24V
<b>Current consumption:</b>	max. 1,25 A
<b>Power consumption:</b>	max. 15 W
<b>Power consumption Standby:</b>	1,6 W

---

**Data interfaces**

---

<b>EIA 232</b>	Sub-D 15 Pol
<b>Ethernet</b>	RJ45
<b>USB</b>	USB-A socket for stick

---

**Connections**

---

<b>Input voltage</b>	Sub-D 15 Pol
<b>Sensore</b>	Sub-D 15 Pol
<b>Encoder</b>	Sub-D 15 Pol
<b>In / Outputs</b>	Sub-D 15 Pol
<b>Traffic light</b>	Sub-D 15 Pol

---

**Performance data**


---

<b>Cable length System unit / Power supply</b>	1,8 m (5.9 ft)
<b>Text layout</b>	Software Z1 Remote Manager
<b>Parameter input</b>	Software Z1 Remote Manager
<b>Fonts (optional)</b>	All available Windows fonts customer-specific fonts
<b>Print height</b>	1 to 12,7 mm (0.04 to 5 inch.)
<b>Max. print resolution<sup>1)</sup> in dpi</b>	300/600
<b>User language Software:</b>	Italian, German, English, French, Spanish, Japanese
<b>Barcodes<sup>1)</sup></b>	EAN 8, EAN 13, EAN 128, Code 2/5, Code 2/5 check, Code 39, Code 39 check, Code 128, DUN14, GS1 Databar
<b>2D-Codes<sup>1)</sup></b>	Datamatrix, GS1 Datamatrix, OR-Code, PPN-Code
<b>Automatic functions<sup>1)</sup></b>	Date, Time, Counter, customer-specific links
<b>Graphic</b>	Monochrome bitmap- graphics can be created i.e. with Paint or other software.
<b>Print image storage</b>	9 print images
<b>Print image length</b>	23.600 Pixel = 1m at 300dpi
<b>Storage; optional expandable in GB</b>	1
<b>Storage in MB</b>	32

<b>Max. print speed in at 300dpi, depending on resolution)</b>  <i>Advanced</i>  <i>Pro</i>	60 m/min (196.5 ft/min) 90 m/min (295.3 ft/min)
<b>Print direction</b>	L/R or R/L, from top or side. Print from bottom is <b>not</b> possible.

<sup>1)</sup> Not available in all versions

The preferred print direction is from left to right. When printing from right to left, the minimum print start is 25 mm to the box front edge. If a lower distance is desired, an external photo sensor must be installed or the system can be modified to left-hand.

## Inks

Specification	Type
<b>Black</b>	INK ZL01 WD THERMAL BLACK
	INK ZL02 ED THERMAL BLACK
	INK ZL03 WP THERMAL BLACK
	INK ZL04 WP THERMAL BLACK

---

## 4. Transport, Packaging and Storage

### Transport

---

Check the delivery for completeness and transport damages immediately upon receipt.

Proceed as follows in case of externally visible transport damage:

- Decline delivery or accept with reservation only.
- Record extent of damage in the transport documentation or on the delivery note of the carrier.
- Initiate complaint.

### Scope of Delivery

---

The scope of delivery depends on the ordered options and the customer's application. Please control the scope of delivery when receiving the systems on the basis of the delivery note.

Scope of Delivery - Basic:

- 1 x System unit

Optional:

- Power supply 24V / 15W
- USB-Stick
- Operating Manual on the USB-Stick
- Z1 Remote Manager-Software on the USB-Stick
- Mounting bracket
- Ethernet cable 3 m (9.8 ft)
- External product sensor
- Encoder




---

## Symbols on Packaging

---

As part of the installation and further use it may happen that the operator put user or maintenance personnel in charge of handling of packages. Therefore note the following important notes:



### **This way up**

The arrowheads indicate the top of the package. They must always face upward to avoid damage to the content.

---



### **Fragile**

Identifies packages with fragile or sensitive contents.

Handle the package with care, do not drop or subject to impacts.


---



### **Keep dry**

Keep packages away from moisture and keep dry.

---



### **Protect from heat**

Protect packages from heat and direct sunlight.

---

---

## Transport and Unpacking

---

### Safety Instructions

---

**NOTICE****Material damage due to incorrect transport!**

Remove the packaging material and the transportation safety devices on installation site and transport the print system in its original packaging to the place of installation.

**CAUTION****Danger due falling parts!**

- Wear safety shoes!

---

## Packaging

### On Packaging

---

The individual packages are packed in accordance with the expected transport conditions. Only environmentally-friendly materials were used for packaging.

Packaging serves to protect the individual components against transport damage, corrosion and other damage, up to the assembly stage. Do not, therefore, damage the packaging - remove shortly before assembly only.

**Original packaging is available from the manufacturer to ensure optimal dispatch of the system.**

**Please contact your local distributor.**

---

### Handling of packaging materials

---

Dispose of packaging material in accordance with the applicable statutory provisions and local regulations.

#### **NOTICE**

#### **Environmental damage!**

Packaging materials are valuable raw materials and can, in many cases, be re-used or profitably recycled and re-used.

Therefore:

- Dispose of packaging materials in an environmentally-responsible manner.
  - Observe the locally applicable disposal regulations. If necessary, commission a specialized company for disposal.
-

## Storage

### Controller

---

Store the controller under the following conditions:

- Do not store outdoors.
- Keep dry and free of dust.
- Do not expose to aggressive media.
- Keep away from direct sunlight.
- Avoid mechanical shock.
- Storage temperature: 5°C to 45°C.
- Relative humidity: maximum 60% not condensing.

### Ink cartridge

---

New original sealed ink cartridges have a shelf life of up to 1 year. Observe the printed expiry date! The shelf life of different cartridge types differs.

#### Storage under 2 days:

Leave the ink cartridges in the print head holder and wipe off or rinse, if necessary, before restart.

#### Storage over 3 days:

Insert the ink cartridge in a cartridge clip (CartClip).

### Store Ink cartridge

---

If ink cartridges are not used for an extended period of time, they must be stored in a cartridge clip (CartClip) to prevent the ink in the nozzles from drying out.

To do this, the ink cartridges must be removed from the controller.

### Instruction

To insert the ink cartridge in the CartClip:

---

Step	Procedure
1	Insert the ink cartridge in the CartClip. The nose of the cartclip to the back slightly until the cartridge click into place. (see Fig. 4-1)



Fig. 4-1: Inserting the ink cartridge in the CartClip

---

### Instruction

To remove the ink cartridge from the CartClip:

Step	Procedure
1	Pull the nose of the cartclip to the back slightly and remove the cartridge.



Fig. 4-2: Removing the ink cartridge in the CartClip

---

## 5. Construction and function

### Brief description

---

The Z1 is a thermal Inkjet Coder of Zanasi s.r.l., for printing images quickly and cleanly onto smooth and absorbent product surfaces.

A print image, for instance, contains product descriptions, graphics, quantities, shelf life data, barcodes and product serial numbers.

The print images can be created directly with PC installed Remote Manager Z1 software and can be loaded in/or sent to the Zanasi Z1 by means of a USB stick or a network.

Up to 9 print images can call up for printing via keyboard.

The Z1 comprises the controller and an external 24V power supply

### Controller

---

The Zanasi Z1 comprises essentially a controller with integrated control electronics, cartridge bay with clamp and the connections for the power supply, shaft encoder, external photo sensor, in-/outputs at the back side of the system. At the top are a keypad with 4 control LEDs and a USB-A socket for a data transfer via USB-Stick.

The system unit is directly installed with a optional mounting bracket on the production line. The coder consists of a system unit and a ink cartridge from Funai-Lexmark.

Standard the cartridge holder is mounted on the right side also referred to as right-hand.

The preferred print direction is from left to right. When printing from right to left, the minimum print start is 25 mm (0.98 inch.) to the box front edge. If a lower distance is desired, an external photo sensor must be installed. Or the system can be modified to left-hand.

The preferred print direction is than from right to left. When printing from right to left, the minimum print start is 25 mm (0.98 inch.) to the box front edge.

---

## **Ink cartridge**

---

The ink is contained in the cartridge ink ducts and the viscosity and surface tension of the ink prevents it from running out.

A heating element, which generates a steam bubble when current is briefly applied (0,8  $\mu$ s), is fitted behind each jet opening.

This steam bubble gives the ink between the heating element and the jet opening an impulse and therefore “shoots” a defined quantity of ink out of the opening.

When the steam bubble reforms, a corresponding quantity is drawn from the storage container and the process can begin again. This process of ejecting an ink drop can be repeated 18,000 times a second.

Print images 1 mm to 12.7 mm (0.04 to 0.5 inch.) high can be produced with a wide variety of fonts.

Various special inks are available for coding on many different surfaces.

---

**The system is optimized for Funai-Lexmark cartridges.**

**The ink settings (Fire pulse, spitting, warming) will set optimal by using Funai-Lexmark cartridges.**

**These values cannot determine and set by using other cartridges. Then the ink level is 1% (warning level).**

## System versions

The print system is available in 2 different versions:

*Advanced e Pro.*

The print system will be delivered as Advanced version standard. If the requirements exceed the scope of services of the Advanced version, an upgrade with costs to the Pro versions is available.

Le specifiche delle due versioni separate si trovano nella tabella che segue.

FUNCTION	SYSTEM VERSION	
	<i>Advanced</i>	<i>Pro</i>
<b>max. Speed at 300 dpi</b>	60	90
<b>Layout length</b>	1m (3.28 ft)	2m (6.56 ft)
<b>DPI horizontal</b>	50 - 900	50 - 900
<b>DPI vertical</b>	300 / 600	300 / 600
<b>Fonts</b>	Printer + TTF	Printer + TTF
<b>Number of layouts</b>	9	9
<b>Text fields</b>	Yes	Yes
<b>Counter fields</b>	Yes	Yes
<b>Date fields</b>	Yes	Yes
<b>Date offset</b>	Yes	Yes
<b>Logos</b>	Yes	Yes
<b>Barcodes</b>	Yes	Yes
<b>2-D Codes</b>	No	Yes
<b>Action fields</b>	Yes	Yes
<b>USB-Stick Data transfer</b>	Yes	Yes
<b>Ethernet interface</b>	Yes	Yes



FUNCTION	SYSTEM VERSION			
	<i>Advanced</i>	<i>Pro</i>		
Password		No	No	
Spitting		Yes	Yes	
Warming		Yes	Yes	
RS232		Yes	Yes	
Internal sensor		Yes	Yes	
External sensor		Yes	Yes	
Encoder		Yes	Yes	
In-/ Outputs		2I / 4O	2I / 4O	
Ink level display		LED	LED	

## Complete overview Z1




Fig. 5-1: Z1 right-hand-model

No.	Description
1	CONTROL PANEL WITH ENTRY KEYS AND LED-STATUS LIGHTS
2	FRONT PANEL
3	INK CARTRIDGE
4	OPENING FOR INTERNAL PRODUCT SENSOR (LIGHT BARRIER)
5	CARTRIDGE NOZZLE PLATE




Fig. 5-2: Z1 Z1 right-hand-model

No.	Description
1	USB-A SOCKET
2	NETWORK CONNECTION (RJ45)
3	SUB-D 15 POL
4	INK CARTRIDGE CLAMP
5	GROUND CONNECTION




Fig. 5-3: Z1 right-hand-model

No.	Description
1	MOUNTING RAIL; OPTIONAL EXTRAS
2	FASTENING POINTS (M4)

---

**Right-hand-/left-hand-model**

---

The Zanasi Z1 is delivered as right-hand-model standard. I.e. the preferred print direction is from left to right. When printing from right to left, the minimum print start is 25 mm to the box front edge. If a lower distance is desired, an external photo sensor must be installed or the system can be modified to left-hand. Both models are shown in the figure below.




Fig. 5-4: Z1 in Righthand- and Lefthand-model

## Flexible bracket (Flexbracket)

The Flexbracket is an optional available mounting bracket, which adjust a variable distance up to 20 mm between print system and product. The print system is provided with a special formed deflector and a linear movable bracket.

The print system is mounted on the production line that the product hit the deflector. The print system is pressed in position, against the spring power of the Flexbracket. After the product passes the print system moves the print system by spring power back in starting position.

**The Flexbracket should use for print speeds up to 30 m/min. For higher speeds is a constant guide not guaranteed and the print result can be manipulate negative.**




Fig. 5-5: Z1 with Flexbracket and universal mounting bracket

---

No.	Description
1	CONTROL SYSTEM
2	FLEXBRACKET DEFLECTOR
3	FLEXBRACKET
4	MOUNTING RAIL
5	CLAMP BRACKET

---

## Name plate

---

The nameplate is attached to the bottom of the system and displays the following:

- System type
- Serial number
- MAC-address
- Article number
- Supply voltage
- Power consumption
- Address of manufacturer



## 6. Installation and Initial Operation

### Safety notes



**Risk of stumbling posed by dirt, objects lying about and connecting lines!**



**RISK OF INJURY!**

Dirt, objects lying about and connecting lines for power, data- and signal lines may cause slipping and stumbling resulting in severe injuries.

Therefore:

- Always keep working area clean.
- Remove objects no longer required.
- Mark stumbling areas with yellow-black marking tape.
- Non tension connecting lines to system and pass it that no places of danger do arise



**Edges and corners pose risk of injury!**



**RISK OF INJURY!**

Sharp edges and pointed corners may cause abrasions and cuts to the skin.

Therefore:

- Be cautious when working near sharp edges and pointed corners.
- If in doubt, wear protective gloves.

## Installation

---

Only an optimally aligned installation of the system can ensure a continuous operation

with a low rate of failures and a minimum wear. For an optimized installation of the system, fine tunings adapted to environmental conditions are essential. For the fine tunings, a complex expert knowledge is required basing on experience with print technique.

The complexity of a wear-optimized installation requires a high measure of specialized knowledge and experience, which cannot be obtained completely by reading this manual. Therefore the installation of the print system must be made by a technician from your local distributor or examined by a final inspection. Damage or damages based on an incorrect installation, represent no case of warranty.

## Requirements to the Site of Installation

---

When choosing the installation location the following conditions apply:

- Consider the generally accepted ergonomic criteria in accordance with workplace ordinances as well as country-specific legislation.
- The installation location must be a dry and dust-free room, ideally with an ambient temperature of approx. 18...25 °C.
- The installation location may not be subject to fast temperature fluctuations (condensation!).
- Do not set up the controller directly next to or above hot surfaces, since this will affect cooling of the controller.
- If the controller is operated on a tripod (accessory), the stability of the tripod on an even foundation must be ensured.
- The controller may not be exposed to flammable, explosive, corrosive gases or chemical vapors.
- The controller may not be installed in the vicinity of high voltage equipment or power supplies.
- The controller may not be subjected to direct vibrations or shocks.
- Keep controller away from oil or water.
- The controller may not be exposed to strong magnetic or electric fields.

---

## Placing the Print System

---

- The installation position has to provide sufficient access for user and service technician.
- Observe that all mounting parts are fixed sufficiently.
- Consider all points of the "Intended Use" in the chapter safety regulations.

To achieve a clean, sharp print result the distance from the product to be printed to the cartridge nozzle plate is important. The optimum distance is 0 to 4 mm between the deflector and the product. A greater distance will adversely affect the print result, particularly at high conveyor belt speeds.

The higher the print speed the shorter must be the distance. At speeds of less than 20 m/min a distance of up to 8 mm between the nozzle plate and the product may still be acceptable.

---

## Flexbracket installation

---

**NOTICE****Material damage due to improper print system installation!**

With the print system switched on, a defect may occur in the system electronics.

Therefore:

- Only install the system when it is switched off.
- 

## Required Resources

- Screwdriver Torx®, SW TX10
- Allen key® SW 2,5
- Allen key®, SW 3

## Instruction

Please install the Flexbracket as follows:

Step	Procedure
1	Disconnect both fixing bolts (this will be used again) of the deflector and remove it from the system unit (see Fig. 6-1).




Fig. 6-1: Disassembly deflector

2	Put the Flexbracket-deflector on the system unit and tighten it with both fixing bolts (see Fig. 6-2).
---	--




Fig. 6-2: Flexbracket-deflector installation

3	If a mounting rail is already mounted under the system unit, disconnect the fixing bolts and remove the mounting rail (see Fig. 6-3).
---	---

Step	Procedure
------	-----------




Fig. 6-3: Disassembly mounting rail

4	<b>The slide of the Flexbracket must be pull in such a position that the borings for the insertion and tightening of the fixing bolts are available. Furthermore the pull spring at the Flexbracket must be push away laterally.</b>
---	--

Set the fixing bolts in the counterbore of the Flexbracket. Positioning the Flexbracket on the system unit and tighten (see Fig. 6-4).




Fig. 6-4: Flexbracket installation

5	Proceed with the installation
---	-------------------------------

---

## Positioning the Print System

---

**NOTICE****Material damage due to improper print system installation!**

With the print system switched on, a defect may occur in the system electronics.

Therefore:

- Only install the system when it is switched off.
- 

**NOTICE****Possible material damages!**

Product mounting rails prepared by the customer protect the system unit from vibrations and damage whilst the product is passing the system unit. (Position B in Fig. 4)

---

### Required Resources

- Setscrew wrench (Allen key<sup>®</sup>)

### Instruction

Please install the print system as follows:

Step	Procedure
1	Attach mounting brackets to the production line.
2	Insert the mounting rail fitted underneath the controller into the clamping piece of the mounting holder and lock.

---

Step	Procedure
------	-----------




Fig. 6-5: Installation of the Z1 at the production line

- |          |   |
|----------|---|
| <b>3</b> | Set the distance from the print head to the product surface. A distance of 0 to 8 mm is optimal. (see Fig. 6-5) |
|----------|---|

---

## Connecting the Print System

---

**NOTICE****Possible material damages!**

To prevent faults due to potential differences, an electro-conductive connection between control unit and conveyor belt must be established.

---

**NOTICE****Material damage due to induced currents!**

If the connection cables of the controller run close to high voltage or heavy current cables in the cable duct, induction may cause malfunctioning or damage.

Therefore:

- Lay all connection cables of the controller spatially separate from high voltage and heavy current cables.
- 

The Print system needs electricity for its functions.



## Overview of the print system connectors




Fig. 6-6: Electrical connections

No.	Description
1	ETHERNET
2	OPTIONS
3	USB-A
4	GROUND CONNECTION

---

## Ground print system

---

### Instruction

Please connect the ground connection of the print system with ground connection of the conveyor as follows:

Step	Procedure
1	Connect the ground connection of the print system with ground of the conveyor.

---




Fig. 6-7: Ground connection at the print system

---

## Connecting to Supply Voltage

---

### Requirements


- Power supply according to "Technical Data" is installed close (max. 1,5 m away) to the printing site.

### Instruction

Please connect the print system with supply voltage as follows:

Step	Procedure
1	Enclosed the power supply are several country-specific power plugs. Mount the right power plug to the power supply (see Fig. 6-8).

---

Step	Procedure
	
	Fig. 6-8: Installation power plug
2	Connect the power plug to the power socket on the Z1. (DC 12V-24V).
3	Connect the power pack with the power supply.

## Connecting the encoder

If more options will be used simultaneously, a splitter-cable can used.

### Requirements

- The optional shaft encoder is mounted at the production line.
- Ideally runs the measuring wheel of the shaft encoder on the conveyor belt, near the print system.

### Instruction

Please connect the optional shaft encoder with the print system as follows:

Step	Procedure
1	If necessary install the optional shaft encoder on the production line and connect it to the option-connection socket.




Fig. 6-9: Option-Socket (Sub-D 15-pole) on the system-back and Sensor-LED on the top side of the system

2	Set the system-clock to Shaft encoder by the Z1 Remote Manager software. (System settings – Print parameter)
3	Set the shaft encoder resolution by the Z1 Remote Manager software 600 dpi with the delivered shaft encoder from Zanasi. (System settings – Print Parameter)

---

Step	Procedure
4	Set the intensity by the Z1 Remote Manager software so, that the desired effective resolution can be reached. (System settings – Print parameter)
5	The Sensor / Encoder LED lights red, if the shaft encoder isn't connected or doesn't rotate.

---

## Connecting the optional Product Sensor

**If more options will be used simultaneously, a splitter-cable can used.**

### Requirements

- The optional shaft encoder is mounted at the production line.
- The sensor is mounted in product running direction, near the Zanasi Z1
- Between the sensor and the nozzle plate is maximum a product, because another print activation is otherwise ignored

### Instruction

Please connect the optional product sensor with the print system as follows:

Step	Procedure
1	If necessary install the optional shaft encoder on the production line and connect it to the option-connection socket.




Fig. 6-10: Option-Socket (Sub-D 15-pole) on the system-back and Sensor-LED on the top side of the system

2	Set the sensor input of the system to External by the Z1 Remote Manager software. (System settings – Advanced settings)
3	The Sensor LED lights green with print activation from product identification to the end of the print.
4	If no print image is loaded, the Sensor LED lights yellow as long as the sensor is covered.

## Connection to a network

A RJ-45-connection allows a connection of the print system to the customer LAN (Local Area Network).

The LED on the top of the system lights green if a network is available. The LED flashes yellow with data communication.

### Instruction

Please connect the print system with the network as follows:


Step	Procedure
1	If required connect the print system to the network by a RJ45 socket.
	
2	Set the desired IP address by the Z1 Remote Manager software. (System settings – System Config – IP-Address)
3	Add the system in the Z1 Remote Manager software to operate it by the Z1 Remote Manager software. (Connections – Add system – Enter name and IP address)

Fig. 6-11: Ethernet-socket (RJ 45) on the system-back and network LED on the top side of the system.

**Each IP address can place in a network once only. Otherwise there is an address conflict and the system can't address. Please contact your system administrator.**

## Inserting Ink Cartridge

**If a new ink cartridge is inserted, the cartridge counters must be reset.**

**Use the ink cartridge as soon as possible after having removed the protective foil or the cartclip.**

### Instruction

Please insert the ink cartridge in the print system as follows:

Step	Procedure
1	Remove the protective foil or CartClip from the nozzle plate and insert the ink cartridge in the holder.
2	Before replacement of the cartridge, wipe the nozzle plate once with a lint-free cloth.
3	Move the stop lever for the ink cartridge in the unlocked position.
4	Insert the ink cartridge in the cartridge holder vertically and push the cartridge forward with the lever. (see Fig. 6-12).




Fig. 6-12: Insert the ink cartridge

5	Lock the stop lever for the ink cartridge.
---	--

**The correct position of the ink cartridge is displayed in the main menu. The LED lights green after a correct insertion.**



---

## Removing Ink Cartridge

---

**NOTICE****Damages by misuse!**

An electronic fault can't waive with a going print process and simultaneous removing of the cartridge.

Therefore:

- Only change the cartridge when the print process is stopped.
- 

**Instruction**

Please remove the ink cartridge from the print system as follows:

Step	Procedure
1	Unlock the stop lever for the ink cartridge.
2	Remove the ink cartridge from the cartridge holder. (see Fig. 6-13)




Fig. 6-13: Remove the ink cartridge

## 7. Operation

### User interface of the print system




Fig. 7-1: User interface on the top side of the system

When starting the system unit the progress of the starting process can be monitored on the LED's. If errors occur during booting, an error code is transmitted via the LED's and can be analyzed in more detail.

---

## Switching ON


---

### Requirements

- The print system is connected with power.
- The system is in standby-mode

### Instruction

Please switch the print system on as follows:

Step	Procedure
1	Press short on the [ON-/OFF]-Button on the top side of the print system.
	
<small>Fig. 7-2: ON-/OFF-BUTTON on the top side of the system</small>	
2	The system conducts a self-test and is ready to use after approx. 10 seconds.

---

## Switching OFF


---

### Requirements

The print system is connected with power and switched on.

### Instruction

Please switch the print system off as follows:

Step	Procedure
1	Keep the [ON-/OFF]-Button on the top side of the print system pressed for approx. 10 seconds. The print system passes to standby mode.
	
Fig. 7-3: ON-/OFF-BUTTON on the top side of the system	
2	The Status LED flashes every 10 seconds shortly in the standby-mode.
3	Disconnect the power supply from the print system for a completely switch off.

---

## Print Stop

---

### Instruction

Please activate a Print Stop / a Print Pause as follows:

Step	Procedure
1	Presses once short the [ON-/OFF]-Button on the top side of the print system.




Fig. 7-4: ON-/OFF-BUTTON on the top side of the system

---

2	The Power LED lights yellow on print stop.
---	--

---

---

## Print Start

---

### Instruction

Please activate a Print Start as follows:

Step	Procedure
1	Presses once short the [ON-/OFF]-Button on the top side of the print system.




Fig. 7-5: ON-/OFF-BUTTON on the top side of the system

---

2	The Power LED lights green with successful print activation.
---	--




---

## Select Print Image

Up to nine print images can be saved in the memory of the Zanasi Z1 for a direct call up at the system unit.

### Instruction

Please select a print image as follows:

Step	Procedure
1	To select the saved print image, ranks third (3.00I), press the [SELECT]-Button three times short.
	
Fig. 7-6: SELECT-BUTTON on the top side of the system	
2	To confirm the text selection pressing the [ON-/OFF]-Button within 5 seconds.
	
Fig. 7-7: ON-/OFF-BUTTON on the top side of the system	
3	After pressing the [ON-/OFF]-Button, the selected text is confirmed with the flashing STATUS LED. I.e. if text 3 is selected, the STATUS LED flashes three times.
	
Fig. 7-8: Status-LED on the top side of the system	
4	The print images 1.00I to 9.00I can selected for printing in this way.

## Loading Print Image

---

Print Images can load to the Zanasi Z1 print system as follows:

- USB-Stick
- Software Z1 Remote Manager with existing network connection via RJ45 or
- By serial interface EIA 232

Load print images incl. fonts, logos and parameter with a USB-stick automatically.

The files can load to a USB-stick by Z1 Remote Manager.

After the connection of a USB stick an automatic run of commands will be made to query the system status.

At the same time a directory „Zanasi“and a subdirectory with the name of the serial number of the system, i.e. „P11905-z1“ will be created in the main directory of the USB stick. There will be saved all system specific data.

The stick must be connected once on the system to post this information, so that the iDesign software can work with the system after that.

The transfer of the data and commands happen by the directly after the connection of the stick. After this the „Status.ast“ file is created.

### **Process:**

After the connection and identification of the stick, the data will be read from the stick and the Status LED flashes quickly meanwhile (4x/second)

Thereafter, data written on the stick and the Status LED flashes slowly meanwhile (2x/second)

If the LED lights constant, the stick can be removed after 2 seconds.

## Load print image with a USB-Stick

### Needed tools



- USB-Stick

### Requirements

- The used USB stick was connected for a „Initializing“ to the print system.
- The print image, created with the Z1 Remote Manager Software, is transferred to the USB stick.

### Instruction

Please load the print image from the USB-Stick to the memory of the print system:

Step	Procedure
1	Connect the USB-Stick to the USB-socket on the top side of the print system.
	
<p>Fig. 7-9: : USB-A socket on the top side of the system</p>	
2	Wait until the data exchange is completed. The STATUS LED flashes during the data exchange and lights constant after finishing.
	
<p>Fig. 7-10: STATUS-LED on the top side of the system</p>	
3	Remove the USB-Stick from the print system (2 seconds after the LED flashes constantly).

**If the USB-stick is removed early or during data transfer, a data loss can happen.**





## Set print start delay

Change the print start delay with a key combination.

### Instruction

Please set the print start delay on the system as follows:

Step	Procedure
1	Press the [SELECT]-button and [ON-/OFF]-button to increase the print start delay.
	
Fig. 7-11: SELECT-BUTTON and ON-/OFF-BUTTON	
2	The delay increases about 1 mm with each keypress
3	Press the [SELECT]-button and the [INK]-button to decrease the print start delay.
	
Fig. 7-12: SELECT-BUTTON and INK-BUTTON	
4	The delay decreases about 1 mm with each keypress.

---

## Loading Print Image with Z1 Remote Manager

---

### Requirements

- The Zanasi Z1 print system is connected with the Z1 Remote Manager Software by a network or serial interface

### Instruction

Please load a print image from Z1 Remote Manager to the memory of the Zanasi Z1 print system as follows:

Step	Procedure
1	Select the menu Functions on the left side of Z1 Remote Manager
2	If several print systems are connected with the Z1 Remote Manager software, click on the illustration of the corresponding print system which shall be selected.
3	Click on the button [Printing].
4	Select the desired directory by pressing the directory button. The print images, saved in Z1 Remote Manager can be found in the directory C:\user\public\Z1 Remote Manager\label standard.
5	Click to select the desired print image. The selected print image is shown in the preview.
6	Click on the button [Print start] to print the selected print image. A window with "Print start ok" is shortly shown for the confirmation.

Step	Procedure
------	-----------




Fig. 7-13: Print image selection in Z1 Remote Manager

---

## Setting of the parameter by Z1 Remote Manager software, i.e. Print Start Delay

---

The print start delay can be set in this menu, i.e. by how much is printing delayed in millimeters after the product is detected by the product sensor.

The delay can be selected between 0 and 999 millimeters (0-39.33 inch.).

The print start delay relates to the beginning of the print layout.

### Requirements

The Zanasi Z1 print system is connected with the Z1 Remote Manager software via a network or serial interface or the data can be transferred via USB-Stick.

### Instruction

Please set the print start delay via the Z1 Remote Manager software as follows:

Step	Procedure
1	Select the menu Functions on the left side of Z1 Remote Manager.
2	If several print systems are connected with the Z1 Remote Manager software, click on the illustration of the corresponding print system which shall be selected.
3	Click on the button [Settings].
4	Click on the menu slide „Print parameter“ to call up the corresponding menu.
5	Set up the print start delay by click on the arrow keys or by input via keypad.

Step	Procedure
------	-----------




Fig. 7-14: Set up the print start delay in Z1 Remote Manager

## To rinse the nozzles manually

### NOTICE

#### Material damage due to splashing ink!

During spitting, splashing ink soils the surroundings.

Therefore:

- Hold an absorbent cloth in front of the ink cartridge nozzle plate.

After extended periods of no printing, it may be necessary to rinse the ink cartridges to open up clogged nozzle channels again.

During rinsing (purging), all ink cartridge nozzle ducts are addressed to eject some ink. The rinse process takes max. 2 seconds or rather so long as the button will be pressed and hold.

#### Needed tools

- Absorbent cloth
- Or paper / cardboard

#### Instruction

Please rinse the nozzle channels as follows:

Step	Procedure
1	Hold a absorbent cloth on front of the nozzle plate of the ink cartridge.
2	Press the [ON / OFF]-button and the [INK]-button on the top of the system simultaneously.




Fig. 7-15: [ON / OFF]-button and [INK]-button on the top of the system

3	Wipe the nozzle plate off carefully to remove excess ink.
---	---

## Calculate ink content cartridge

---

An ink cartridge contains ca. 1,083 bn ink droplets of approx. 24 pl each. The system counts the ink droplets printed and uses this to calculate the ink consumption.

The number of prints, which can be done with one cartridge, can be read in the menu.

The ink content can also be determined by weighing:

A full LX cartridge weighs ca.  $66 \text{ g} \pm 3 \text{ g}$ . An empty cartridge weighs ca.  $40 \text{ g} \pm 3 \text{ g}$ . The rest of an empty cartridge is max. 3 ml.

## Web-Interface

The WEB Interface can only be called from one terminal at the same time!


If the WEB Interface of a print system should be operated by another terminal, the existing connection must stop before!

After starting the WEB Interface, the status screen is displayed, from which can be navigate.




Use the arrow keys to scroll through the print image.


By a click on the print image, the print image name, the number of the previously print image and the number of prints of the selected print image, which can be print with a full cartridge, are displayed.








The print can pause with .




The print can start again or another print image can select with .





The selected print image can start with .

The last loaded and paused print image restarts with .

Variable fields are queried each time before a print image starts:





Parameter settings can be selected and changed with :





With the  button:


- a print image can call up for print start
- a print image can be changed
- a new print image can be created.



Change the ink settings with .



Call up and change the system settings with :



## Configurable In-/Outputs

### NOTICE

#### Material damage due to short-circuit!

The outputs are open Collector outputs and may load with max. 100 mA.

The Z1 has at the 15-pole option socket two in- and four outputs. A variety of configurations are possible and so the connectors for output of status messages (OK, Warning, Error), cartridge level messages (5% low / empty), print ready and print pulse are possible to use. On the input side signals for heating, spitting, print direction, upside print, stop and text selection are possible.

The texts for input 1 must be called „!EXT01.00!“ and „!EXT02.00!“ with an external text selection by the inputs. The texts „!EXT01.00!“ to „!EXT04.00!“ can be assigned if both inputs are used.

The setting can be done with Z1 Remote Manager Software in *Functions* → *System settings* → *Advanced settings* or via Web-Browser in *Settings* → *Advanced settings*.




Fig. 7-16: User interface Software Z1 Remote Manager

## Settings by Z1 Remote Manager software

Following print parameter can set up with the Z1 Remote Manager software (Note the instructions of the provided Z1 Remote Manager software manual):

- Print start delay
- Print direction
- Zoom
  
- Fixed speed
- Speed (Only adjustable if fixed speed is adjusted)
- Intensity (Only adjustable if fixed speed is adjusted)
  
- Shaft encoder
- Shaft encoder resolution (only adjustable if shaft encoder is adjusted)




Fig. 7-18: Set print parameter by Z1 Remote Manager

## 8. Z1 Remote Manager

### Create a print image

No print images can be created on the **Z1** system unit itself.

Print images can be created and processed with the software Z1 Remote Manager software stored on the USB stick. For this purpose, this must be installed on a commercially available PC (follow the enclosed Z1 Remote Manager operating instructions).

The diagram below shows the operating surface of the Z1 Remote Manager software




Fig. 8-1: User interface Editor Z1 Remote Manager



---

## Ethernet Connection establishing

---

To establish an Ethernet connection to the printer you have to know a free Ethernet address.

Please ask your system administrator.

### Instruction

How to set the Ethernet address in the system:

Step	Procedure
1	Connect a USB stick to the Z1 and wait that the status LED stops blinking.
2	Connect the USB stick to a PC with Z1 Remote Manager software. The system will be shown in Z1 Remote Manager.
3	Click in Z1 Remote Manager with the mouse on the system icon and enter the requested IP address under Functions / Settings / System / IP address.  Confirm the IP address and add the connection to Z1 Remote Manager.
4	Now connect the USB stick again to the Z1.  The Z1 should now be visible under the desired IP address.

---

## 9. Faults

The following chapter describes possible causes of malfunctions and how to remedy these.

In case of frequent faults, reduce the service intervals depending on the actual work load.

**Please contact your local distributor with regard to faults that cannot be remedied with the information provided below.**

### Safety

#### Staff

- The fault remediation work described here, unless specified otherwise, can be performed by the operator.
- Some tasks may only be performed by specially trained specialized staff or exclusively by the manufacturer; this is specifically pointed out in the description of the individual faults.
- Work on the electrical system may only be performed by electricians.



**Danger to life through electric shock!**



**DANGER TO LIFE!**

Contact with live parts poses imminent danger to life.  
Damaged insulation or individual components can be lethal.

Therefore:

- Immediately switch off the power supply and initiate repairs if the insulation is damaged.
- Work on the electrical system may only be performed by electricians.
- Before working on the electrical system, disconnect from the mains (remove mains plug) and check that power is off.
- Always disconnect mains before performing cleaning and repair tasks.
- Keep moisture from live parts. Moisture may cause a short-circuit.



**Risk of injury by improper fault remediation!**



**WARNING!**

Improper fault remediation may cause severe injury to persons, or material damage.

Therefore:

- Ensure adequate working space before starting any work.
  - Keep the working area clean and tidy! Loosely stacked or scattered components and tools are potential causes of accidents.
-

## Table of faults

Faults	Possible causes	Troubleshooting	Recovered by
System unit does not start	No power supply	Check power supply	Electrician
	No 12V/24V DC	Check 12V/24V, Change power supply	Electrician Instructed Person
System unit does not produce a print image	System on Standby	Press On / Off button	Instructed Person
	Print image not assigned	Assign print image	Instructed Person
	Stop print	Start print	Instructed Person
	Missing start pulse	Check photo sensor and connection cable	Electrician
	Missing ink cartridge	Insert ink cartridge	Instructed Person
	Empty ink cartridge	Insert new ink cartridge	Instructed Person
	Defect ink cartridge	Insert new ink cartridge	Instructed Person
	Dry up ink cartridge	Clean ink cartridge	Instructed Person
	Ink cartridge not inserted correctly	Remove and reinsert ink cartridge	Instructed Person
	Print parameter incorrect	Check print parameter, adjust if necessary	Instructed Person
Fault in the electronics of the controller or the print head	Send controller or print head in for repairs	Manufacturer	

<b>Faults</b>	<b>Possible causes</b>	<b>Troubleshooting</b>	<b>Recovered by</b>
	Faulty rotary encoder or incorrect rotary encoder settings	Check rotary encoder and encoder settings	Instructed Person
Bad and fuzzy print image	The distance between print head and product is too big	Reduce distance to 0 -4 mm ...5 mm	Qualified person
	Low intensity	Increase intensity	Instructed Person
	Empty ink cartridge	Change ink cartridge	Instructed Person
	Blocked nozzles	Spitting and wipe the nozzle plate if necessary.	Instructed Person

---

## Trouble shooting tasks

---

### Cleaning the ink cartridge

---

**NOTICE****Material damage due to incorrect cleaning!**

Incorrect cleaning may scratch the nozzles of the ink cartridges, causing blurred print images since the scratches around the nozzles divert the ink.

Therefore:

- Use only lint-free and absorbent cloths to clean the cartridges.
  - Moisten cleaning cloths with water.
  - Wipe slowly without pressure.
- 

- To be done by instructed person.
- To be done if print quality deteriorates during printing or after extended period of non-use.

During printing the print quality may deteriorate due to dust and ink vapor. In this case, wipe the nozzle plate of the ink cartridge with a moist, lint-free cloth. The water in the moist cloth dissolves the ink residues and cleans the nozzles and the ink channels.

#### Needed tools

Absorbent cloth

#### Instruction

Please clean the nozzle plate as follows:

Step	Procedure
1	Remove the ink cartridge from the holder.
2	Hold the ink cartridge with the nozzle plate facing downward.
3	Slowly wipe across the nozzle plate in the direction of the arrow, using a moistened and lint-free cloth.  Do not shake the ink cartridge!




Fig. 9-1: Cleaning the nozzle plate (the image doesn't show the Funai-Lexmark cartridge)

4	Reinsert the ink cartridge in the holder
---	--

**A small amount of water may mix with the ink in the channels, rendering the first print a bit grey.**

## 10. Disassembly

When end of the useful life expires, the system must be disassembled and disposed in an environmentally-friendly manner.

### Safety

### Staff

---



**Danger to life through electric shock!**



**DANGER TO LIFE!**

Contact with live parts poses imminent danger to life.  
Damaged insulation or individual components can be lethal.

Therefore:

- Immediately switch off the power supply and initiate repairs if the insulation is damaged.
- Work on the electrical system may only be performed by electricians.
- Before working on the electrical system, disconnect from the mains (remove mains plug) and check that power is off.
- Always disconnect mains before performing cleaning and repair tasks.
- Keep moisture from live parts. Moisture may cause short-circuit.





**Risk of injury caused by improper disassembly!**



**WARNING!**

Stored residual energy, sharp-edged components, points and corners on and inside the apparatus or on the required tools may cause injuries.

Therefore:

- Ensure adequate space before starting any work.
  - Handle exposed sharp-edged components with care.
  - Keep the work area clean and tidy! Loosely stacked or scattered components and tools are potential causes of accidents.
  - Secure components to prevent falling down or falling over.
  - Consult the manufacturer if uncertain.
- 

- Disassembly may only be performed by specially trained specialized staff.
- Work on the electrical system may only be performed by electricians.

## Disposal

---

**NOTICE****Environmental damage due to incorrect disposal!**

Electrical scrap, electronic components, lubricants and other auxiliary materials are subject to hazardous waste treatment regulations and may only be disposed of by approved specialized companies!

---

Unless return or disposal agreements were made, submit disassembled components for recycling:

- Scrap metals.
- Submit plastic components for recycling.
- Dispose of other components according to material composition.

The local municipal authorities or specialized disposal companies provide information on environmentally compatible disposal.

## 11. List of Accessories and Spare Parts

### NOTICE

#### Safety hazard due to incorrect spare parts!

Incorrect or faulty spare parts may affect safety and cause damage, malfunctions or failure.

Therefore:

- Only use original spare parts from the manufacturer.

Procure spare parts via contracted dealers or directly from the manufacturer.

### Ink cartridges

### NOTICE

#### Material damage can be caused by spraying ink!

Spitting results in increased ink consumption and can lead to undesirable contamination of the environment.

Therefore:

- Hold an absorbent cloth in front of the nozzle plate of the ink cartridge.

**The specified drying times can be reduced by additional heat treatment (hot-air blower, IR heater). The open time can be extended by spit pulse programming. di.**

**Please note** the ink specific settings for head voltage, fire time, spitting and warming.

There is the possibility to set up the ideally standard values for the respective ink type on the Z1 Remote Manager software or Web interface.

It makes sense to change the values carefully depending on the application.

The settings can be made with the Z1 Remote Manager software below **Functions / System settings / Advanced settings**.

Pos	Name	Description
1	INK ZL01 WD THERMAL BLACK	Ink cartridge, color black, 33 ml capacity each. Specially developed water-based ink of Funai-Lexmark.
2	INK ZL02 ED THERMAL BLACK	Ink cartridge, color black, 48 ml capacity each. Specially developed solvent-based ink of Funai-Lexmark. Well suited for prints on semi-absorbent and non-absorbent materials, depending on the intensity <b>Open time without loss of quality:</b> Up to 8 hours.
3	Ink ZL03 WP Thermal Black	Ink cartridge, color black, 33 ml capacity each. Specially developed, high pigmented, water-based Funai-Lexmark ink. Well suited for sharp edged print on poorly absorbent materials. <b>Drying:</b> Immediate drying on absorbent surfaces, no drying on poorly absorbent surfaces, because the pigments remain on the surface. <b>Open time without loss of quality:</b> Approx. 30 minutes (depending on intensity and print image).
4	INK ZL04 WP THERMAL BLACK	Ink cartridge, color black, 33 ml capacity each. Specially developed, high pigmented, water-based Funai-Lexmark ink.

## Settings Spitting and Warming






Fig. 11-1: Z1 Remote Manager advanced settings







Refer to the Z1 Remote Manager Manual.

## Mounting brackets

Pos.	Article	Description
1	Universal mounting bracket	for a fixing on a conveyor from the side, with quick fastener to take the system unit out of the mounting bracket without technical tools.
2	Universal mounting bracket TOP	for a fixing on a conveyor from the top, with quick fastener to take the system unit out of the mounting bracket without technical tools.
3	Flexbracket Kit for Z1	flexible bracket to compensate variable distances between control system and product. Maximum travel length 20mm; maximum print speed 30 m/min.

## Other

Pos.	Figure	Assembly	Description
1		Power supply	Power supply Z1 24V
2		Mounting bracket	Universal Mounting bracket
3		Mounting bracket Top	Universal Mounting bracket Top
4		Photocell	Including 2.5 m connecting cable

Pos.	Figure	Assembly	Description
5		Encoder	Push-pull output, 2,500 pulses/rev. Splitter cable necessary
6		USB data stick	
7		Splitter cable	Splitter cable for the connection of more than 2 options, alarm, RS232, sensor, encoder
8		Box	Box for connecting all the accessories
9		Alarm light	Alarm light 3 color
10		Flexbracket kit	consisting of: -Flex bracket deflector -Flex bracket -Screws

## 12. Appendix

### Ink Chart

The Zanasi Z1 has a deposit ink chart. The optimal parameter of an ink will be automatically adopted by the ink selection.

If the parameters were changed in the Z1 Remote Manager software, the changed parameters stay active till a new ink type will be select.

The ink tables are stored as excel tables in the HMI account : "InkParLX.csv".

The chart can be adapted customized with an HMI update and can load to the memory of the Zanasi Z1.

**Changes of the ink parameter can cause bad print images and should conduct from specialized staff.**

„InkParLX.csv“:

Set- No.	Set- No.	Volume	Voltage	Fire Time	Spit Spitting	Spit Rows	Spit Delay	Warming	Warm Temp	Warm Time	Pre fire
1	1	100	110	190	Off	0	0	No	20	0	33
2	2	80	110	72	Off	0	0	Si	47	2	25
3	2	80	110	70	Off	0	0	Si	42	2	25
4	3	80	110	70	Off	0	0	Si	42	2	25



## Software-Update

### Software-update with USB-Stick

- The program directories „HMI“, „Html“ and „SYSTEM“ are copied in the main directory of an empty USB-stick.
- The Z1 is not connected to the power supply.

### Instructions

Please proceed the software-update as follows:

Step	Procedure
1	By pressing the [Ink]- button, connect the Zanasi Z1 with the power supply until the Sensor LED flashes green/red.
2	Connect the USB-stick in the USB socket on the top side of the system.
3	The Sensor LED flashes yellow/red if the program is load.
4	Confirm by pressing the start-button and wait until the system is restart.
5	Remove now the USB-stick.

## Software-Upgrade

A software upgrade with costs is comfortably possible.

Please contact your consultant or local distributor to get a software-upgrade

### Current software version

Status	Date	Info
2.0.10.1	Dic.2015	

## USB-Stick files

---

Following files are saved on the USB-stick:































- Z1 Remote Manager Software
- Manual Z1 Remote Manager Software
- Manual Z1
- Leaflet

The required files for software updates:

- HMI-directory
- HTML-directory
- System-directory

## Boot-LED messages

During booting of the system progress can be determined by means of the LED.  
If the system stops during booting the cause can be determined by means of the LED.  
FC means flashing. An error can be determined on the basis of the number of flashes.

Status-LED 	Sensor-LED 	Description
 ye	 ye	Boot BF-Intern
 rd	—	Write 64MB memory
—	 rd	Read 64MB memory
 ye	—	Read/Test 64MB memory
—	 ye	Test ok / Load BootMain from SPI
 ye	 rd	Programming and Start of BootMain
—	—	BootMain Initialization
 rd	 rd	Fatal Error
 rd	FC:  rd	Boot Error 4x = SPI; 5x = GA; 6x = Displ; 7x = SD-Card; 8x = USB; 9x = RTC; 10x = Task
 rd	FC:  gr	Init Error 1x = Dev; 2x = FS; 3x= UsrCl
 ye	 gr	Read SD-Card
 ye	 rd /  gr	Wait for stick
 ye	 rd / —	No boot data
 ye	 ye /  gr	Booting of stick
 ye	 ye /  rd	Copying of stick
 ye	 gr / —	Copy ok
 gr	—	Main program loaded and started

---

## Plug connections

### Voltage input

---

**Operating voltage:** 12 - 24V direct current, min 1,25A

**Connector:** Sub-D Plug male 15pin

PIN	Description	Value	Unit
1	GND	0	V
15	Power min 1250 mA	+12-24	V

---

## Ethernet

### Connection

Network input RJ 45 on the back side of the system.

PIN	Description
1	Transmit +
2	Transmit -
3	Receive +
6	Receive -

---

**USB A**

---

The USB sockets are standard sockets, as used in commercial PCs and USB devices. Insert the USB-stick without force effect normal to the top side of the system in the USB socket.

<b>PIN</b>	<b>Name</b>	<b>Color</b>	<b>Description</b>
1	VCC	Red	+5 V
2	D-	White	Data -
3	D+	Green	Data +
4	GND	Black	Mass

---

**Option**


---

**Option socket:** 15 pol Sub-D connector **Option socket:** 15 pol Sub-D connector

PIN	Description	Value	Unit
1	GND	0	V
2	Output 1 (Alarm)	Open Collector, max 24V / 100mA	
3	Input 1	Input Standard: NPN	
4	Input 2	Input Standard: NPN	
5	Output 3 (OK)	Open Collector, max 24V / 100mA	
6	Output 4 (Reserve)	Open Collector, max 24V / 100mA	
7	EIA 232	TXD	
8	GND	0	V
9	Output 2 (Warning)	Open Collector, max 24V / 100mA	
10	Start pulse	Input Standard: NPN	
11	Shaft encoder	Input Standard: NPN	
12	Not used		
13	Not used		
14	EIA 232	RXD	
15	Power	+12-24	V

## Splitter cable

Pin-configuration:

<b>15 pole Sub-D-connector male (label: Z1)</b>	<b>15 pole Sub-D-connector female (label: Full)</b>
PIN 1 (GND)	PIN 1 (GND)
PIN 2 (OUTPUT 1: ALARM)	PIN 2 (OUTPUT 1: ALARM)
PIN 3 (INPUT 1)	PIN 3 (INPUT 1)
PIN 4 (INPUT 2)	PIN 4 (INPUT 2)
PIN 5 (OUTPUT 3: OK)	PIN 5 (OUTPUT 3: OK)
PIN 6 (OUTPUT 4: RESERVE)	PIN 6 (OUTPUT 4: RESERVE)
PIN 7 (TX)	PIN 7 (TX)
	PIN 8 (GND – WITH PIN 1)
PIN 9 (OUTPUT 2: WARNING)	PIN 9 (OUTPUT 2: WARNING)
PIN 10 (SIGNAL SENSOR)	PIN 10 (SIGNAL SENSOR)
PIN 11 (SIGNAL ENCODER)	PIN 11 (SIGNAL ENCODER)
PIN 14 (RX)	PIN 14 (RX)
PIN 15 (POWER)	PIN 15 (POWER)

<b>15 pole Sub-D-connector male (label: Z1)</b>	<b>15 pole Sub-D-connector female (label: Power)</b>
PIN 1 (GND)	PIN 1 (GND)
	PIN 8 (GND – WITH PIN 1)
PIN 15 (POWER)	PIN 15 (POWER)

---

<b>15 pole Sub-D-connector male (label: Z1)</b>	<b>15 pole Sub-D-connector female (label: Sensor - Encoder)</b>
PIN 1 (GND)	PIN 1 (GND)
	PIN 8 (GND – WITH PIN 1)
PIN 10 (SIGNAL SENSOR)	PIN 10 (SIGNAL SENSOR)
PIN 11 (SIGNAL ENCODER)	PIN 11 (SIGNAL ENCODER)
PIN 15 (POWER)	PIN 15 (POWER)



---

**Sensor**


---

**Sensor input:****Standard:** NPN (switching to GND)**Voltage:** 12V-24V depends on the input voltage**Threshold level:** 7V

If switching the input to PNP a resistor of 2kOhm (12V) or 4kOhm (24V) must be connected between input (Pin10) and ground (Pin1)

---

**Encoder**


---



**Encoder input:****Standard:** Push-pull or NPN (switching to GND)**Voltage:** 12V-24V depends on the input voltage**Threshold level:** 7V**Frequency:** Max. 150 kHz

If more systems should be connected together the sensor and encoder signal can be connected parallel. Max. 5 systems because of the power used.

The +12V power should be only connected between one system and sensor / encoder not between the systems !

15 pol Sub-D- female	15 pol Sub-D- male	15 pol Sub-D- male	Up to 5 systems	15 pol Sub-D- male	15 pol Sub-D- female
PIN 1 – GND	PIN 1	PIN 1	PIN 1	PIN 1	PIN 1
PIN 8 – GND	PIN 8	PIN 8	PIN 8	PIN 8	PIN 8
PIN 10 – ftc	PIN 10	PIN 10	PIN 10	PIN 10	PIN 10
PIN 11 – Encoder	PIN 11	PIN 11	PIN 11	PIN 11	PIN 11
PIN 15 – +12V	PIN 15	Not connected	Not connected	PIN 15	PIN 15

## Input and Output



## Mac Address

The MAC address of the respective **Zanasi Z1** can be seen on the name plate of the system. In addition, the Mac address can be seen in the Z1 Remote Manager software.

### Instruction

Please see the MAC address by the Z1 Remote Manager software as follows:

Step	Procedure
1	Select the menu Functions on the left side of the Z1 Remote Manager software.
2	If several print systems are connected with the Z1 Remote Manager software, click on the illustration of the corresponding print system which shall be selected.
3	Click on the button [System Settings].
4	Click on the menu slide „System Config“ to call up the corresponding menu.
5	The MAC address can be seen in the corresponding line.




Fig. 12-1: Z1 Remote Manager System Config

**Range from:**








00:50:C2:A6:50:00

**to:**




00:50:C2:A6:5F:FF

Technical Drawings




System unit Zanasi Z1



## System unit with mounting bracket



## System unit with Flexbracket and mounting bracket



## Parameter List

Parameter	After Reset	Min.	Max.	Current value	Unit
Print Start delay	10 (0.39)	0 (0)	999 (39.33)		mm (inch.)
Speed	15 (49.2)	1 (3.28)	300 (984.25)		m/min (ft/min)
Divider shaft encoder	4	1	50		-
Intensity	300	50	900		dpi
Print width	100	10	900		%
Direction	Dx-->Sx	Dx-->Sx	Sx--> Dx		-
Nozzle row	A~B	A	A+B		-
Overhead	no	no	yes		-
Sensor	Internal	Internal	Esternal		-
Encoder	Internal	Internal	Esternal		-
IP-address		0.0.0.0	255.255.255.255		-
IP-mask	255.255.255.0	0.0.0.0	255.255.255.255		-
Gateway	0.0.0.0	0.0.0.0	255.255.255.255		-
Voltage	11,0	4,0	11,2		V
Fire time	190	50	300		s
Fire pause	190	100	300		s
Ink min	5	0	99		%
Spit mode	Off	Before	Interval		-
Columns	1	1	99		-
Delay	1	1	999		s

Parameter	After Reset	Min.	Max.	Current value	Unit
Interval	1	1	999		s
Auto Off	0	1	999		min.
Ripeat Delay	0 (0)	0 (0)	999 (39.33)		mm (inch.)
Ripeat Number	0	0	999		
Warming	No	Yes	no		
Warming Temp.	20	20	80		°C
Warming off timer	0	0	999		s
Language	Inglese				-
Ink Type	???				-
User 1	0	0	4		-



---

**Declaration of conformity**


---



We hereby declare under our responsibility that the system:

**System Description:** Ink jet printer  
**Type:** Z1  
**Identification:** from serial number AG-TJ-00001  
**Manufacturer:** Zanasi s.r.l.  
 via Marche 10, 41049 Sassuolo (Modena), Italy

complies with the requirement:

**Directive 2014/30/EU (ELECTROMAGNETIC COMPATIBILITY - EMC)**  
**Directive 2014/35/EU (LOW VOLTAGE)**

and has been designed and manufactured in accordance with the harmonized European standards:

<b>EN55022</b>	<b>Interfering voltage</b>
<b>EN55022</b>	<b>Interference field strength</b>
<b>EN61000-6-2</b>	<b>Interference resistance against electromagnetic fields</b>
<b>EN61000-6-2</b>	<b>Interference resistance against high frequency on cables</b>
<b>EN61000-6-2</b>	<b>Interference resistance against ESD</b>
<b>EN55024</b>	<b>Interference resistance against Burst</b>
<b>EN61000-6-2</b>	<b>Interference resistance against Surge</b>
<b>EN55024</b>	<b>Interference resistance against voltage changes and interrupts</b>
<b>EN61000-3-2</b>	<b>Limits of harmonic current emissions</b>
<b>EN61000-3-3</b>	<b>Limits of voltage changes, fluctuation and flicker</b>

The manufacturer keeps information about the system technical construction data.

Person authorised to compile the technical file:

**Paolo Zanni (technical manager) - via Marche 10, 41049 Sassuolo (Modena), Italy**

Sassuolo (Mo), July 15th, 2016

Gianni Zanasi (Managing Director)



Release 8.150716

