

**Z1**



**SO SMALL  
SO BIG**

**PRINT SAMPLE GUIDE**




**Zanasi Z1** is the new Thermal Ink Jet system made by Zanasi, added with the aim to extend the opportunities given to the customers.

This model, able to print with very high resolution (up to 900 horizontal dpi and up to 600 vertical dpi) on different surfaces is the suitable solution in many applications. With a vertical printing area up to 12,5 mm the **Zanasi Z1** can print alphanumeric texts, logos or barcodes.

**PRINT SAMPLES\***

EXP 9-30-2019  
LOT A62835T

Lot. Nr.: 107310  
Active ingredient: Paracetamol  
Identify Nr.: 6218215.01.00



*Compliments* de **ID. S.**  
MEILLEUR AVANT 7 OCTOBRE, 2018  
BEST BEFORE



(01)07612345678900  
(17)130107  
(10)12345678A

Lot.Nr.: 093303  
Active ingredient: Aceclofenac  
Identify Nr.: 6460123.01.00  
Keep away from children

\* The resolution of the print samples on this document is less than the real resolution on the product due to the scanning of the prints.



Message Editor of **Zanasi Z1** software allows the customer to know exactly how many prints per cartridge is it possible to make with the message created for each type of ink.

### CONSUMPTION CALCULATOR\*

Print sample	DPI	Print/Cartridge
EXP 9-30-2019 LOT A62835T	600	111.000
EXP 9-30-2019 LOT A62835T	500	133.000
EXP 9-30-2019 LOT A62835T	400	166.000
EXP 9-30-2019 LOT A62835T	300	221.000
EXP 9-30-2019 LOT A62835T	250	266.000
EXP 9-30-2019 LOT A62835T	220	302.000

Print sample	DPI	Print/Cartridge
Lot. Nr.: 107310 Active ingredient: Paracetamol Identify Nr.: 6218215.01.00	600	109.000
Lot. Nr.: 107310 Active ingredient: Paracetamol Identify Nr.: 6218215.01.00	500	130.000
Lot. Nr.: 107310 Active ingredient: Paracetamol Identify Nr.: 6218215.01.00	400	163.000
Lot. Nr.: 107310 Active ingredient: Paracetamol Identify Nr.: 6218215.01.00	300	217.000
Lot. Nr.: 107310 Active ingredient: Paracetamol Identify Nr.: 6218215.01.00	250	261.000
Lot. Nr.: 107310 Active ingredient: Paracetamol Identify Nr.: 6218215.01.00	220	296.000

\* The resolution of the print samples on this document is less than the real resolution on the product due to the scanning of the prints.



Zanasi Z1 is very performing not only on consumption as we have seen, but even regarding speed related to DPI. In the chart below the relation between horizontal DPI.

**SPEED CHART\***

Horizontal DPI	Vertical DPI	Print Sample	Speed m/min
120	300/600	EXP 9-30-2015 LOT A62835T	225
150	300/600	EXP 9-30-2015 LOT A62835T	180
180	300/600	EXP 9-30-2015 LOT A62835T	150
200	300/600	EXP 9-30-2015 LOT A62835T	135
240	300/600	EXP 9-30-2015 LOT A62835T	112
300	300/600	EXP 9-30-2015 LOT A62835T	90
360	300/600	EXP 9-30-2015 LOT A62835T	75
400	300/600	EXP 9-30-2015 LOT A62835T	67
480	300/600	EXP 9-30-2015 LOT A62835T	56
600	300/600	EXP 9-30-2015 LOT A62835T	45

\* The resolution of the print samples on this document is less than the real resolution on the product due to the scanning of the prints.

